What 3D printer can print car parts?

Asked 3D Content Team
Published October 13, 2026 · Last verified October 13, 2026

Abstract. A car-part printer needs the material's numbers: 270 °C and an 80 °C bed for PETG trim, an enclosure for ASA, 300 °C and a hardened nozzle for carbon-fiber nylon.

Keywords: replacement-parts, enclosures, asa, nylon

Table 1. What the printer needs for each kind of car part

Car part	Typical material	Nozzle (°C)	Bed (°C)	Enclosure	Hardened nozzle	Other
Shaded interior trim, clips, covers	PETG (glycol-modified PET)	240 to 270	60 to 80	Recommended in a cold room	No	None
Sun-facing interior and exterior trim	ASA (acrylonitrile styrene acrylate) or ABS (acrylonitrile butadiene styrene)	240 to 280	90 to 100	Yes	No	None
Engine-bay brackets and covers	Polycarbonate (PC)	260 to 290	100 to 120	Yes	No	None
Engine-bay brackets and covers	Carbon- or glass-fiber nylon (PA-CF, PA-GF)	260 to 300	100 to 120	Yes	Yes	None
Grommets, bumpers, seals, cable boots	TPU (thermoplastic polyurethane), 85A or harder	200 to 250	35 to 45	No	No	Direct-drive extruder
Panels bigger than the bed	Any of the above	As its row	As its row	As its row	As its row	Cut into pieces

1 What 3D printer can print car parts?

Any desktop printer that meets the material's numbers. PETG interior clips need a hotend reaching 270 °C and an 80 °C bed. ABS and ASA trim add an enclosure and a 100 °C bed. Carbon-fiber nylon for under the hood needs 300 °C (572 °F), a 120 °C bed and a hardened steel nozzle.

1.1 What the printer needs for each kind of car part

Nozzle, bed, enclosure and nozzle-material figures come from Bambu Lab's filament guide (nozzle ranges ±10 °C, bed ranges for a textured PEI, polyetherimide, or engineering plate). The ABS and ASA enclosure rule is also in Prusa's Knowledge Base, the 85A floor is from Bambu Lab's TPU guide, and the direct-drive advice is from Simplify3D's materials guide.

Prusa's Knowledge Base runs close: 255 °C nozzle and 100 °C bed for ABS, 260 °C and 105 to 110 °C for ASA, 275 °C and 110 to 115 °C for PC. Its ASA bed and its 60 to 75 °C TPU bed both sit above Bambu Lab's ranges, so follow the label on your spool.

1.2 Why the enclosure and the hardened nozzle matter

ABS, ASA, PC and nylon shrink as they cool. Without warm air around the part, the corners lift off the bed and layers split.

Bambu Lab's guide says these materials need higher bed and chamber temperatures "to suppress warping and layer separation," and it lists open-frame printers as not recommended for them. Prusa calls ASA's warping significant and says an enclosure is necessary for large ASA parts. The enclosure versus heated chamber page explains how much warmth a passive box adds.

Carbon and glass fibers are abrasive. Bambu Lab says to always use a hardened steel nozzle for them, and that brass and stainless steel nozzles "wear out quickly." Plain PC and ABS don't need one.

TPU is soft enough to buckle when pushed. Simplify3D says most fully flexible filaments need a direct-drive extruder, with the drive gear as close to the melt zone as possible, rather than a Bowden tube that lets the strand coil.

Fumes are the other reason for a closed box. Bambu Lab says ABS and ASA release styrene at printing temperature, and tells you to print them in an enclosed printer and keep the room ventilated.

1.3 3D printer for car interior parts

Sun-facing interior parts need ASA or ABS, so the printer needs an enclosure. Shaded parts can be PETG, which prints on an open-frame machine.

Researchers at Arizona State University and UC San Diego measured dashboards averaging 157 °F (69 °C) after an hour in the sun. Bambu Lab lists the heat deflection temperature




Figure 1. Shrinking materials need warm air around the part, fiber-filled filament needs a hardened steel nozzle, and TPU needs the drive gear close to the melt zone.

(the point where a loaded test bar bends) at 57 °C for its PLA Basic and 100 °C for its ASA. A dash vent, a phone mount or a pillar trim clip belongs in ASA.

A clip in a door pocket or under a seat stays cooler, and PETG covers it. Material choice by part is on which filament to use for a replacement part.

1.4 Is a 3D printer big enough to print car parts?

For clips, knobs, bezels, brackets and vent fins, yes. Bumpers, fenders and full dash panels outgrow every desktop build volume, so they get printed in pieces.

Two common desktop size classes, one example of each:

Table 2. Is a 3D printer big enough to print car parts?

Printer (manufacturer)	Build volume, mm	Build volume, in
P1S (Bambu Lab)	256 × 256 × 256	10.1 × 10.1 × 10.1
CORE One L (Prusa Research)	300 × 300 × 330	11.8 × 11.8 × 13.0

Figures from the Bambu Lab P1S spec sheet and Prusa Research's CORE One product page, which lists the CORE One L.

A part bigger than that gets cut in the slicer. PrusaSlicer's cut tool adds plug, dowel or snap connectors across the cut so the pieces locate when you glue them. Large parts in high-shrink materials have their own limit: Prusa says polycarbonate isn't suitable for objects covering the whole sheet, so a long PC part warps even when it fits.

1.5 How to check your own printer can do it

1. Find the hotend and bed maximums on the spec sheet (Bambu Lab's P1S sheet calls them Max Hot End Temperature and Max Build Plate Temperature). Compare each with the top of the material's range in the table.
2. Check whether the printer has an enclosure, and what its nozzle is made of. A brass or stainless steel nozzle rules out carbon- and glass-fiber filament until you fit a hardened steel nozzle.
3. Read the maker's supported-filament list. The P1S sheet, for example, splits materials into "Ideal," "Capable" and "Not Recommended."
4. For TPU, check whether the extruder is direct drive or Bowden.
5. Print a test coupon before the real part: a long, flat bar with square corners in the material you'll use. Prusa notes that sharp corners warp more than round ones, so lifted corners or split layers on the coupon mean the printer needs more enclosure warmth or a hotter bed for that material.

1.6 Which car parts not to print

Never print parts for brakes, steering, suspension, wheels, seat belts and other restraints, airbags or the fuel system. A failure there injures someone, and no data sheet figure makes a printed part safe for those systems.

On warranty, US law is on your side within limits. The FTC says your warranty stays in effect if you use aftermarket parts, and the maker must prove a part caused the damage before denying coverage. In 2018 FTC staff warned automakers, among others, that tying coverage to their own parts is generally prohibited by the Magnuson-Moss Warranty Act. If a printed part fails and damages a covered component, the maker can deny coverage for that component and charge you for the repair. The legal limits on printing replacement parts cover patents and trademarks.

References

[1] Filament guide: printer, nozzle, AMS, build plate, glue compatibility and required parameters, Bambu Lab Wiki. https://wiki.bambulab.com/en/general/filament-guide-material-table. Accessed October 13, 2026.

[2] ABS / ASA / PC Usage Guide, Bambu Lab Wiki. https://wiki.bambulab.com/en/filament/abs_asa_pc. Accessed October 13, 2026.

[3] TPU Printing Guide, Bambu Lab Wiki. https://wiki.bambulab.com/en/knowledge-sharing/tpu-printing-guide. Accessed October 13, 2026.

[4] ABS, Prusa Knowledge Base. https://help.prusa3d.com/article/abs_2058. Accessed October 13, 2026.

[5] ASA (Prusa Knowledge Base). https://help.prusa3d.com/article/asa_1809. Accessed October 13, 2026.

[6] Polycarbonate (PC), Prusa Knowledge Base. https://help.prusa3d.com/article/polycarbonate-pc_165812. Accessed October 13, 2026.

[7] Flexible materials, Prusa Knowledge Base. https://help.prusa3d.com/article/flexible-materials_2057. Accessed October 13, 2026.

[8] Ultimate Materials Guide: Flexible Filament (Simplify3D). https://www.simplify3d.com/resources/materials-guide/flexible/. Accessed October 13, 2026.

[9] Cut tool, Prusa Knowledge Base. https://help.prusa3d.com/article/cut-tool_1779. Accessed October 13, 2026.

[10] Bambu Lab P1S Technical Specifications, Bambu Lab. https://store.bblcdn.com/s7/default/9e9c1948dd61491199a52c3f1497b9c7/bambu-lab-P1S-tech-specs.pdf. Accessed October 13, 2026.

[11] Prusa CORE One+ (Gen 2) product page, with MK4S and CORE One L comparison, Prusa Research. https://www.prusa3d.com/product/prusa-core-one/. Accessed October 13, 2026.

[12] Study: Hot cars can hit deadly temperatures in as little as one hour (ASU News, on Vanos et al., Temperature, 2018). https://news.asu.edu/20180516-discoveries-asu-study-hot-cars-can-hit-deadly-temperatures-within-one-hour. Accessed October 13, 2026.

[13] Auto Warranties and Auto Service Contracts (FTC Consumer Advice). https://consumer.ftc.gov/articles/auto-warranties-and-auto-service-contracts. Accessed October 13, 2026.

[14] FTC Staff Warns Companies that It Is Illegal to Condition Warranty Coverage on the Use of Specified Parts or Services (FTC press release, 2018). https://www.ftc.gov/news-events/news/press-releases/2018/04/ftc-staff-warns-companies-it-illegal-condition-warranty-coverage-use-specified-parts-or-services. Accessed October 13, 2026.

Cite as: Asked 3D. “What 3D printer can print car parts?.” October 13, 2026. https://asked3d.com/answers/3d-printer-for-car-parts. Last verified October 13, 2026.